


CLAYMORE uf5

CLAYMORE UF5




User Manual

Please follow the user manual before use.
If any abnormality is found in the product, discontinue use and contact the dealer or a service center where the product was purchased. Any modifications of this product will void the warranty. Misuse of CLAYMORE products may cause user harm.


Caution

- ① Do not use near high temperatures such as fires or heating equipments.
It may cause explosion or ignition.
- ② This product is water resistant. However, if left in the rain for a long time, it may cause malfunction.
If the product gets soaked, please quickly wipe it off.
- ③ Do not store or use in vehicles exposed to direct sunlight. It may cause explosion and malfunction.
- ④ Do not use if it exceeds the operating temperature range (-10 °C to 40 °C).
- ⑤ Please do not place in the reach of infants. It may cause swallowing of parts or injury.
- ⑥ Adult supervision is necessary when used by children. Misuse of light may cause injury or electric shock.
- ⑦ Do not insert any metal parts into the terminal block of the connector.
It may cause heat, explosion or electric shock.
- ⑧ Do not disassemble or modify the product.
- ⑨ Do not touch the connector with wet hands. There is a danger of electric shock.
- ⑩ After use, be sure to turn off the power.
- ⑪ Do not forcefully fold connector, It may damage product.
- ⑫ If the product is dropped or experiences physical shock, damage may be accumulated inside the product and unexpected malfunction may occur even during normal use.
Be careful not to apply physical shocks to the main unit.
- ⑬ Please keep in a dry place without moisture.

1. Components




2. Contents




3. Operation

● Connecting to MULTI FACE

Open the rubber cover of the left or right OUTPUT port of the MULTI FACE and connect the connector jack of CLAYMORE UF5. You can connect MULTIFACE and UF5 with a USB A(M)-A(F) extension cable to place UF5 apart from MULTI FACE. ※ App, dimming and LED color changing is available




● LED Lantern Function



ON/OFF

Press and hold button on the MULTI FACE for 2sec to turn on light. (status indicator ON). Repeat to turn off light.



5 STEP Dimming


When light is ON, press button to increase brightness. Repeat to decrease brightness. ※ Light blinks once when Maximum and Minimum brightness is reached.

Tip) If there's no MULTI FACE, it can be used alone by connecting the CABLE to the portable charger

● UF5 + MULTI CONTROLLER + Portable charger


When UF5 is connected to other devices (USB-A for fast charging), it may not work properly. If it does not work, please connect a Multi controller additionally.

Function	Operation
App	X
LED Color	O
Dimming	O



※ Multi controller is not included. ※ App is not available while using Multi controller.

[4 Light Mode]



4. Ways to use


You can use official accessories (Shade, Carabiner) to create a variety of presentations.

● Attaching a shade

You can make a romantic atmosphere by attaching the silicon shade to the bottom

● Attaching a carabiner

You can hang with a carabiner.



5. Specification

Product name	CLAYMORE UF5			
Model No.	CLUF5-01LG/BK			
Color temperature	Warm	Orange	Soft Warm	Breeze
	3000K	1500K	2500K	1500K~3000K
Brightness (With MULTI FACE)	80~1300Lm			
Size	3524x145x60mm			
Weight	436g			
INPUT	USB 5V 2A			
Origin	China			

※ Operating time may vary depending on the battery capacity and external environment

Warranty

Item	CLAYMORE UF5
Model No.	CLUF5-01LG/BK
Seller	
Date of Purchase	

1. Thank you for purchasing CLAYMORE series of Prism Co., Ltd.
2. This product has passed strict quality control tests. If the product is not functioning properly, please contact an authorized service center.

Free Service

- 1) Failure of the product under normal operating conditions during the warranty period will be repaired by Prism or authorized service center on free of charge. Some shipping or handling charges may be involved.
- 2) Warranty period: 1 year.

Charged Service

- 1) Damage caused when the warranty period is over.
- 2) Damage caused due to the user's mishandling, abuse, or improper operation.
- 3) Damage caused by arbitrary or personal repair or disassemble in unauthorized service center.
- 4) Damage from input electricity or cable defect.
- 5) Damage caused by natural disaster.

CLAYMORE

Prism Co., Ltd.

221, Pyeongcheon-ro, Bupyeong-gu, Incheon, Republic of Korea
www.claymorelight.com - www.prismlight.co.kr - info@prismlight.co.kr